


VALVE ASSEMBLY

VALVE ASSEMBLY – 73-06852-51-550		
REF NO	PART NUMBER	DESCRIPTION
1	60-06862-51-550	Valve Assembly
1a	60-08050-51-550	Diaphragm Repair Kit (for item 1)*
1b	16-01192-08-550	Front Cap (included in item 1)
1c	40-07305-08-640	Renewable Seat (included in item 1)
1d	11-01184-08-550	Adjusting Screw (included in item 1)
2	16-06860-08-550	Spud Air Gap
3	10-07082-31-870	Seat Washer
4	10-15449-01-640	Bearing Air Gap
5	11-06873-35-550	Spring
6	11-01133-42-550	Packing Spring
7	11-01134-08-550	Stem Washer
8	10-26454-40-550	O-Ring (2 each)
9	11-27055-51-550	Gasket (2 each)
10	11-00357-42-830	Valve Spring
11	11-42256-42-550	Stem
12	11-01138-08-550	Adjusting Nut
13	16-02530-08-550	Sleeve Lock
14	16-26455-08-640	Valve Incline
15	16-07983-08-640	Vandal Proof Handle
16	16-01136-51-550	Ball Bearing
17	11-05449-42-550	Set Screw
18	16-07987-08-640	Handle Cap
19	60-09880-51-550	Stem Assembly

WHEN ORDERING #18 PLEASE SPECIFY WALL THICKNESS AND WHETHER IT IS IN OR ON THE WALL.



* Look for detailed schematic of this part in **Detailed Parts** Section

To order parts, contact your nearest Halsey Taylor wholesaler or representative.

Continued product improvement makes specifications subject to change without notice.

Halsey Taylor.